

# User manual for FLEXi SP3 security panel with Protegus, Paradox keypads

July 2022



## **Attention!**

Read this user manual carefully.

A representative from the company installing the alarm system will explain which functions of the **FLEXi SP3** security module must be activated to ensure proper protection of the premises.

<b>Copyright</b>	© 2022 UAB "Trikdīs". All rights reserved.
<b>Trademarks and patents</b>	Other trade names used in this document may be trademarks or registered trademarks belonging to their respective manufacturers or retailers.
<b>Manufacturer</b>	UAB „Trikdīs“, Draugystes g. 17, LT-51229 Kaunas, Lithuania
<b>Version</b>	This document is applicable to <b>FLEXi SP3</b> security modules with firmware version v1.00 and up.
<b>Certification</b>	CE marking
<b>European Union directives</b>	2004/108/EC (EMC directive) 1999/5/EC (conformity directive)
<b>Contact information for inquiries</b>	Contact information can be found on the website <a href="http://www.trikdis.com">www.trikdis.com</a>



# Contents

<b>1</b>	<b>ABOUT YOUR ALARM SYSTEM .....</b>	<b>4</b>
<b>2</b>	<b>MAIN TECHNICAL SPECIFICATIONS .....</b>	<b>4</b>
<b>3</b>	<b>POWERING THE EQUIPMENT.....</b>	<b>4</b>
<b>4</b>	<b>GENERAL OPERATION OF THE ALARM SYSTEM .....</b>	<b>4</b>
4.1	TRANSMISSION OF ALERT MESSAGES .....	4
4.2	ALARM SYSTEM OPERATION MODES .....	5
4.3	CONTROL OF THE ALARM SYSTEM .....	5
4.4	CONTROL ACCESS .....	5
4.5	SECURITY FUNCTIONS .....	5
4.6	ADDITIONAL FUNCTIONS .....	6
<b>5</b>	<b>CONTROLLING THE ALARM.....</b>	<b>6</b>
5.1	CONTROLLING THE ALARM WITH A SK232LED W KEYPAD .....	6
5.2	CONTROLLING THE ALARM WITH A PARADOX KEYPAD .....	7
5.3	QUICK ARMING/DISARMING OF THE ALARM SYSTEM.....	9
5.4	ARMING THE ALARM IN ARM MODE .....	9
5.5	ARMING THE ALARM IN STAY MODE.....	9
5.6	ARMING THE ALARM IN SLEEP MODE .....	9
5.7	DISARMING THE ALARM (OFF MODE) .....	10
5.7.1	<i>Switching off the alarm after it has been activated.....</i>	<i>10</i>
5.8	TEMPORARY ZONE BYPASS (BYPASS FUNCTION).....	10
5.9	VIEWING AND CLEARING ALARM ACTIVATION MEMORY .....	10
5.10	RESETTING FIRE (SMOKE) SENSORS.....	11
5.11	EMERGENCY CALL BUTTONS.....	11
5.12	TROUBLESHOOTING THE ALARM SYSTEM .....	11
5.13	PROGRAMMING USER CONTROL CODES.....	12
5.13.1	<i>Changing the administrator code .....</i>	<i>12</i>
5.13.2	<i>Entering new User codes .....</i>	<i>12</i>
5.13.3	<i>Editing User codes .....</i>	<i>12</i>
5.13.4	<i>Viewing partition statuses.....</i>	<i>12</i>
5.13.5	<i>Deleting User codes .....</i>	<i>12</i>
5.13.6	<i>Duress code.....</i>	<i>13</i>
<b>6</b>	<b>CONTROL USING IBUTTON KEYS.....</b>	<b>13</b>
<b>7</b>	<b>CONTROL USING RFID CARDS (TAGS) .....</b>	<b>13</b>
<b>8</b>	<b>CONTROL USING PHONE CALLS .....</b>	<b>13</b>
<b>9</b>	<b>CONTROL USING SMS MESSAGES.....</b>	<b>14</b>
<b>10</b>	<b>CONTROL OF PGM OUTPUTS.....</b>	<b>16</b>



## 1 About your alarm system

The **FLEXi SP3** control panel is part of a premise security and fire alarm system. It performs sensor signal processing and signalizer control and has integrated GSM and WiFi modems that can transmit alert messages to the central monitoring station and to users' mobile phones.

Representatives of the company that installed the alarm system will explain the details on the operation, configuration and control of Your alarm system.

## 2 Main technical specifications

Parameter	Description
Number of security zones	10 zones (20 zones if using ATZ), can be expanded to up to 32 zones using expanders
Number of partitions	Up to 8
Ways of alerting about danger	Sound, indoor and/or outdoor sirens. Strobe lights. Transmission of messages to central monitoring station and/or to users
Alert messages are transmitted	To central monitoring station via GPRS to two addresses and/or via SMS messages To 8 user mobile phones via SMS messages
Safety requirements	Meets safety requirements of the EN 60950 standard
User codes for control	Up to 40 user control codes; allowed number of different <i>iButton</i> keys or RFID cards – up to 40
Resistance to environmental influences class	Meets demands of standard EN 50131 for Class II environmental classification
Operating conditions	Temperature from -10 °C to +50 °C, relative humidity 80% at +20°C, no condensation
Main power supply	230 V 50 Hz single-phase AC power network (through a step-down power transformer). Power consumption no higher than 40 W
Backup power supply	12 V / 7 Ah battery. Current consumption no higher than 0,5 A

## 3 Powering the equipment

The control panel is powered by an AC power network, or, in case it fails, by a backup battery. When an AC power network is available, the battery is charged and kept in standby mode. The time of operation using the backup battery is limited and depends on the amount of current used by the alarm system. A voltage of 12 V is required to power additional equipment.

## 4 General operation of the alarm system

The security-fire alarm system consists of a signal processing board (the control panel), installed in a casing along with a step-down power transformer and backup power supply battery, with intrusion, break-in, fire and other sensors, sound and light signalers and control equipment connected to it.

If the alarm system is armed and any of the sensors are triggered, sound and light signalizers are turned on, and, if set, alert messages are sent to the central monitoring station and to users. If the alarm is disarmed, it will only react to the triggering of sensors that are set to operate continuously.

### 4.1 Transmission of alert messages

Alert messages can be transmitted to the CMS (central monitoring station) and/or to users. Messages are sent via the selected connectivity channels, first to the CMS and only then to users via **Protegus**, SMS messages and/or phone calls.



## 4.2 Alarm system operation modes

Mode	Description
OFF (DISARM)	In this mode, only some of the zones are protected. The alarm will only react to events in zones set to <b>Fire, 24 hour, Silent 24h</b> .
ARM	In this mode, all zones are protected. The alarm will react to all possible events.
STAY	In this mode, a part of the zones is protected, but movement is allowed in zones set to <b>Interior STAY</b> and <b>Instant STAY</b> . If the alarm system is operating in this mode and a <b>Delay</b> zone is violated, the alarm will activate only after the entry time has elapsed.
SLEEP	In this mode, a part of the zones is protected, but movement is allowed in zones set to <b>Interior STAY</b> and <b>Instant STAY</b> . If the alarm system is operating in this mode and a <b>Delay</b> zone is violated, the alarm will activate immediately.

## 4.3 Control of the alarm system

The alarm system can be controlled using the following devices:

- *Trikdis* keypad Protegus SK232LED W;
- *Paradox* keypads K32+, K32LED, K636, K10LED V/H, K35, TM50, TM70;
- *Crow* keypads CR-16, CR-LCD;
- *iButton* keys;
- *RFID* cards;
- Electric switch, by changing the state of the zone selected by the keyswitch;
- Telephone (by phone call or by sending an SMS message with specific contents);
- **Protegus** app;
- Remote command from monitoring station.

## 4.4 Control access

Control codes are used to give different users different access levels for controlling the alarm system. The user control codes are four digits long. When choosing and entering control codes, only numbers from 0 to 9 are used, other symbols are not available.

Types of alarm system control codes:

- Administrator code – a six-digit combination (default code - 123456). There is only one administrator code. It cannot be deleted, but it can be changed. The Administrator code allows to add or delete other users' control codes. The Administrator code cannot arm/disarm the alarm system;
- User code – a four-digit combination for arming/disarming the alarm system and for temporarily bypassing security zones. It is recommended to assign every user a personal alarm control code. The memory of the **FLEXi SP3** module can store up to 40 user codes;
- SMS password – six-digit combination for controlling the alarm system via SMS messages (default code - 123456).

## 4.5 Security functions

Name	Description
Bypass	Temporarily (for one arming of the alarm system) bypasses a security zone when changing the alarm status. The function is used when the alarm needs to be armed, but a zone is malfunctioning and the fault cannot be easily repaired.
Bell Squawk	The module can use a short siren signal to warn about the arming and disarming of the premise alarm system.
Chime	When the alarm is disarmed, the module can warn that a zone is being violated by turning on the keypad buzzer and/or a specially programmed PGM output.



Name	Description
Re-ARM	Used to protect against accidental disarming of the alarm. If the alarm was disarmed via phone call, but the <b>Delay</b> zone was not violated, the alarm will automatically return to its previous security mode after the Entry Delay time passes.


#### 4.6 Additional functions

Name	Description
Temperature measurement	Up to 8 temperature sensors DS18B20, DS18S20 or one temperature and humidity sensor AM2301 can be connected to the <b>FLEXi SP3</b> module. Intervals of permitted temperatures can be set for each of them individually. If the temperature changes beyond the set interval, an event message will be formed and sent to users.
Remote control of devices	Additional electronic devices can be connected to the <b>FLEXi SP3</b> security module's programmable open collector outputs and can be controlled remotely.

### 5 Controlling the alarm

#### 5.1 Controlling the alarm with a SK232LED W keypad

The Trikdis keypad SK232LED W for alarm system control displays the states of 32 zones and 2 partitions.



#### Buttons for setting operation modes and entering numbers

Button	Description
	A constantly glowing button means the alarm system is powered from the AC power network, and a blinking button shows a battery fault. The button is off – the power voltage supply is off or the system is operating using the battery. The button is also used for editing control codes and for resetting fire sensors.



Button	Description
MEM	A constantly glowing button shows that in memory there is new information about the alarm being triggered, and a blinking button shows that the keypad is operating in MEM mode. The button is also used for choosing the memory viewing mode.
BYP	A constantly glowing button means that there are temporarily bypassed zones, and a blinking button shows the keypad is operating in BYP mode. The button is also used for selecting temporary bypass mode.
TRB	A constantly glowing button means that operational trouble has been recorded, and a blinking button shows that the keypad is operating in TBL mode. The button is also used for selecting trouble viewing mode.
1, 2 ...9, 0	Buttons for entering numbers.
C	Button for exiting modes and clearing values.
OK	Button for confirming the specified choice.
ARM	Button for turning on full security mode <b>ARM</b> .
SLEEP	Button for turning on <b>SLEEP</b> mode.
STAY	Button for turning on <b>STAY</b> mode.
OFF	Button for turning on <b>OFF</b> (DISARM) mode.


**Note:**

1. To turn off programming mode or delete an incorrectly entered value, press the [C] button.
2. If at least one zone is violated, it will not be possible to arm the alarm system (if the **FORCE** property is not assigned to the violated zones).

## 5.2 Controlling the alarm with a Paradox keypad


The Paradox K10LED V/H keypad for alarm system control displays the states of 10 zones and 2 partitions.

The Paradox K636 keypad for alarm system control displays the states of 10 zones and 1 partition.





Paradox keypads K32LED, K32+, K35 for alarm system control display the states of 32 zones and 2 partitions.



**Buttons for setting operation modes and entering numbers**

Button	Description
	Button for resetting fire sensors.
MEM	A constantly glowing button shows that in memory there is new information about the alarm being triggered, and a blinking button shows that the keypad is operating in MEM mode. The button is also used for choosing the memory viewing mode.
BYP	A constantly glowing button means that there are temporarily bypassed zones, and a blinking button shows the keypad is operating in BYP mode. The button is also used for selecting temporary bypass mode.
TBL	A constantly glowing button means that operational trouble has been recorded, and a blinking button shows that the keypad is operating in TBL mode. The button is also used for selecting trouble viewing mode.
1, 2 ...9, 0	Buttons for entering numbers.
CLEAR	Button for exiting modes and clearing values.
ENTER	Button for confirming the specified choice.
ARM	Button for turning on full security mode <b>ARM</b> .
SLEEP	Button for turning on <b>SLEEP</b> mode.
STAY	Button for turning on <b>STAY</b> mode.
OFF	Button for turning on <b>OFF</b> (DISARM) mode.
	Power voltage indicator. Constantly glowing – power voltage is turned on. Blinking – battery fault. Off – the power voltage source is off or the system is operating from the battery.

**Note:**

- To turn off programming mode or delete an incorrectly entered value, press the [CLEAR] button.
- If at least one zone is violated, it will not be possible to arm the alarm system (if the **FORCE** property is not assigned to the violated zones).



### 5.3 Quick arming/disarming of the alarm system

Arming/disarming the alarm system using a code when the security system has **STAY** zones.

Security modes **ARM**, **STAY** and **SLEEP** are switched to **OFF/DISARM**, and **OFF/DISARM** is switched to **ARM** or **STAY** mode.

Changing the security mode:

1. Enter [**User code**].
  - a. If the system only has one partition, skip step 2. If the system has more than one partition, the numbers of the partitions that the user is allowed to change the modes of will light up on the keypad.
2. Press the numbers of the chosen partitions.
3. Partitions that were in **ARM**, **STAY** and **SLEEP** modes will switch to **OFF/DISARM** mode.
  - a. When the alarm is off, the [**OFF**] indicator is glowing.
  - b. If the **Bell Squawk** function is enabled, the siren will activate twice for short periods of time as the alarm switches off.
4. **Exit delay** time will be counted down for partitions that were in **OFF/DISARM** mode. If a **Delay** zone is violated during the countdown, **ARM** mode will switch on, and if a **Delay** zone is not violated, **STAY** mode will switch on.
  - a. The respective keypad indicator ([**ARM**] or [**STAY**]) will light up.
  - b. If the **Bell Squawk** function is enabled, the siren will activate once for a short period of time as the alarm switches on.

### 5.4 Arming the alarm in ARM mode

To turn on **ARM** security mode for an alarm system that is divided into multiple partitions:

1. Press the keypad button [**ARM**].
2. Enter the [**User code**] using the keypad.
3. Press the buttons with the numbers of the partitions you want to control.
4. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.
5. Before the **Exit Delay** time runs out, leave the premises and close the door.
  - a. During the **Exit Delay** time countdown, the keyboard indicator [**ARM**] will blink, and when the alarm is armed, it will glow constantly.
  - b. If the **Bell Squawk** function is enabled, the siren will activate once for a short period of time as the alarm switches on.

### 5.5 Arming the alarm in STAY mode

To turn on **STAY** security mode for an alarm system that is divided into multiple partitions:

1. Press the keypad button [**STAY**].
2. Enter the [**User code**] using the keypad.
3. Press the buttons with the numbers of the partitions you want to control.
4. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.
5. The keypad indicator [**STAY**] will light up.
  - a. If the **Bell Squawk** function is enabled, the siren will activate once for a short period of time as the alarm switches on.

**Note:** **STAY** mode is unavailable unless at least one zone is set to **Interior STAY** or **Instant STAY**.

### 5.6 Arming the alarm in SLEEP mode

To turn on **SLEEP** security mode for an alarm system that is divided into multiple partitions:

1. Press the keypad button [**SLEEP**].
2. Enter the [**User code**] using the keypad.
3. Press the buttons with the numbers of the partitions you want to control.
4. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.



5. The keypad indicator [**SLEEP**] will begin to glow.
  - a. If the **Bell Squawk** function is enabled, the siren will activate once for a short period of time as the alarm switches on.

## 5.7 Disarming the alarm (OFF mode)

When the premises are secured in **ARM** or **STAY** mode, the countdown of the **Entry Delay** time will begin if anyone enters the premises. You must disarm the alarm before the time runs out.

To switch off protection mode (switch on **OFF / DISARM** mode):

1. Press the keypad button [**OFF**].
2. Enter the [**User code**] using the keypad.
  - a. If the system has only one partition, skip steps 3 and 4.
3. Press the buttons with the numbers of the partitions you want to control.
4. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.
  - a. When the alarm is off, the indicator [**OFF**] lights up.
  - b. If the **Bell Squawk** function is enabled, the siren will activate twice for a short period of time as the alarm switches off.

### 5.7.1 Switching off the alarm after it has been activated

To switch off the alarm:

1. Enter the [**User code**].
  - a. If the system has only one partition, skip steps 2 and 3.
2. Press the buttons with the numbers of the partitions you want to control.
3. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.
  - a. When the alarm is off, the indicator [**OFF**] lights up.
  - b. If the **Bell Squawk** function is enabled, the siren will activate twice for a short period of time as the alarm switches off.
  - c. The [**MEM**] indicator will light up and violated zones will start blinking. Press [**MEM**] and then [**C**] (or [**CLEAR**]) to stop the blinking of the violated zones.

## 5.8 Temporary zone bypass (Bypass function)

To switch on the **Bypass** function:

1. Press the [**BYPASS**] button on the keypad.
2. Enter the [**User code**].
  - a. The **BYP** indicator will start blinking.
3. Enter the two-digit numbers of the zones that you want to bypass.
4. Confirm your selection by pressing the [**OK**] (or [**ENTER**]) button.
5. The **BYP** indicator will start glowing.

To switch off the **Bypass** function, repeat the same steps as above.

## 5.9 Viewing and clearing alarm activation memory

When the alarm is activated, the indicator [**MEM**] starts glowing. To find out the reason of the alarm activation:

1. Press the [**MEM**] button on the keypad.
2. The glowing numbers indicate which zones caused the alarm to activate.
3. To exit this mode, press the [**C**] (or [**CLEAR**]) button.
  - a. If no actions are performed with the keypad, the memory viewing mode will switch off automatically after one minute, but the memory will not be cleared and the [**MEM**] indicator will continue to glow.
4. The memory will be cleared after the alarm is switched on and the [**MEM**] indicator stops glowing.



## 5.10 Resetting fire (smoke) sensors

After the triggering of fire (smoke) sensors, to reset the sensors you must:

1. Press and hold the keypad button [  ] (or [  ]) for 3 seconds.
  - a. The PGM output that the fire sensors are connected to and that is set to operate in **Fire sensor reset** mode will activate.
  - b. The fire (smoke) sensors connected to the control panel's zone will be reset.

## 5.11 Emergency call buttons

The keypad can be used to send messages to the security company about required help or imminent danger. This feature is only available if you are using the services of a security company and the security system is connected to the central monitoring station.

Hold down the following buttons together for 3 seconds:

- [1] [3] to send a message **Panic** about imminent danger.
- [4] [6] to send a message **Medical** about the need for medical assistance.
- [7] [9] to send a message **Fire**.

## 5.12 Troubleshooting the alarm system

If there is any operational trouble, the [TRB] indicator on the keypad lights up. To view operational trouble of the alarm system:

1. Press the [TRB] button.
2. Trouble groups will light up on the keypad.
3. If you want to view a trouble group, press the corresponding button.
4. To leave troubleshooting mode, press the [C] (or [CLEAR]) button.

### **Trouble descriptions**

Trouble group	Description of selected group
[1]: System	[1] No AC power.
	[2] Battery malfunction.
	[3] Clock not set.
	[4] Maximum allowed current for output AUX is exceeded.
	[5] Maximum allowed current for siren output is exceeded.
	[6] No siren.
	[7] Fire detector loop trouble.
[2]: Communications	[1] Faulty main connectivity channel (all connection types).
	[2] Faulty second connectivity channel (all connection types).
	[3] Faulty <b>Protegus</b> connectivity channel (all connection types).
	[4] No SIM card.
	[5] Incorrect SIM PIN code.
	[6] Unable to connect to GSM network.
	[7] Unable to connect to WiFi network.
	[8] <b>E485</b> module connectivity trouble (see LED indication of the module).
[3]: Zone tamper	Numbers of zones with violated tamper.
[4]: 485 bus	Numbers of 485 bus expanders with malfunctions.



Trouble group	Description of selected group
[5]: Missing RF sensor	A wireless sensor is no longer operational (periodic check time has passed). The zone number shows the order from a separate RF table.
[6]: RF battery low	A wireless sensor has indicated that its battery is about to run out. The sensor number can be found from a separate RF table.
[7]: Anti-masking	Numbers of zones with violated anti-masking.

## 5.13 Programming user control codes

### 5.13.1 Changing the administrator code

The administrator code can be changed in *TrikdisConfig* software's menu branch **System Options / Access / Access codes**.

### 5.13.2 Entering new User codes

1. Press the [] (or []) button on the keypad.
2. Enter the 6-digit **[Administrator code]**.
  - a. The [] (or []) button will begin to blink.
3. Enter a free two-digit user serial number.
4. Enter a 4-digit **[User code]**.
5. Repeatedly enter the 4-digit **[User code]**.
6. Enter the partitions that the user will be able to control.
7. Confirm your selection by pressing the **[OK]** (or **[ENTER]**) button.
8. To leave programming mode, press the **[C]** (or **[CLEAR]**) button.

### 5.13.3 Editing User codes

1. Press the [] (or []) button on the keypad.
2. Enter the 6-digit **[Administrator code]**.
  - a. The [] (or []) button will begin to blink.
3. Enter the desired two-digit user serial number.
4. Enter the 4-digit **[User code]**.
5. Repeatedly enter the 4-digit **[User code]**.
6. Enter the partitions that the user will be able to control.
7. Confirm your selection by pressing the **[OK]** (or **[ENTER]**) button.
8. To leave programming mode, press the **[C]** (or **[CLEAR]**) button.

### 5.13.4 Viewing partition statuses

Viewing states of the current partitions.

Paradox K32+, K32LED, K636, K10LED, K35 keypads	Protegus SK232LED keypads
Press buttons [1] and [2] simultaneously for 3 seconds, the keypad must beep	Press button [2] and hold down for 3 seconds, the keypad must beep

LED indicators numbered from 1 to 8 will show the states of the partitions: On – **Arm** mode is on; Blinking – **Stay** mode is on; Off – **Disarm** or off.

### 5.13.5 Deleting User codes

To delete existing User codes:

1. Press the [] (or []) button on the keypad.
2. Enter the 6-digit **[Administrator code]**.



- a. The [⚡] (or [🔌]) button will begin to blink.
3. Enter the desired two-digit user serial number.
4. Press the [SLEEP] button.
5. To leave programming mode, press the [C] (or [CLEAR]) button.

### 5.13.6 Duress code

If you are forced to switch the alarm system on or off, if you enter your user code with the duress option enabled, the system will switch the alarm system on / off and immediately transmit a silent alarm (Duress code) to the monitoring station. The duress code must be enabled by the installer. There are two types of duress codes: **Higher last digit** or **“0” instead of the first digit**.

## 6 Control using iButton keys

**Note:** If at least one zone is violated, it will not be possible to arm the alarm system.

iButton keys can be used to set the alarm system security modes **ARM / STAY / OFF**. Security mode **SLEEP** is unavailable.

Place the iButton key against the key reader. The mode of the alarm system will change to the opposite mode. If the system was armed, it will disarm. If the system was disarmed, it will arm and the countdown of **Exit Delay** time will start. If the zone set to **Delay** is not violated during the time for exiting and there are zones set to **Interior STAY** and **Instant STAY**, the security mode **STAY** will switch on.

Existing keys can be deleted and new keys added to an installed and functioning alarm system by using the configuration software **TrikdisConfig** or a contact key reader.

Linking keys using the **CZ-Dallas** reader.

1. If the **Tag code** list is empty, place the contact key against the “eye” of the reader and hold for 3 seconds. The key will be linked, added to the first line of the list and become the **Master key**.
2. To turn on contact key linking mode, hold the **Master key** against the “eye” of the key reader for at least 10 seconds.
3. To link user keys, hold them against the “eye” of the key reader one by one.
4. When you are finished linking the user electronic (*iButton*) keys, hold the **Master key** against the key reader again to disable linking mode.
5. To delete all keys (including the master key), hold the **Master key** against the reader for at least 20 seconds.

## 7 Control using RFID cards (tags)

**Note:** If at least one zone is violated, it will not be possible to arm the alarm system.

RFID cards can be used to set the alarm system security modes **ARM / STAY / OFF**.

A Wiegand (26/34) RFID reader with keypad must be connected to the security control panel. RFID tags (cards) can be added by entering their ID numbers in the **TrikdisConfig** software field **Tag code**.

Hold the RFID card against the Wiegand reader or enter the [**User code**] on the Wiegand reader keypad and press [#]. The mode of the alarm system will change to the opposite mode. If the system was armed, it will disarm. If the system was disarmed, it will arm and the countdown of **Exit Delay** time will start. If the zone set to **Delay** is not violated during the time for exiting and there are zones set to **Interior STAY** and **Instant STAY**, the security mode **STAY** will switch on.

## 8 Control using phone calls

**Note:** If at least one zone is violated, it will not be possible to arm the alarm system (if the **FORCE** property is not assigned to the violated zones).

When controlling the alarm using phone calls, only **ARM** and **STAY** security modes are available.

Before calling, it is recommended to check the current security mode by sending a partition state request via SMS message (command: **ASKA 123456**), and also check the current zone states by sending a zone state request via SMS message (command: **ASKI 123456**).



Programming the control panel allows to enter user phone numbers and specify what these users can control using phone calls: arm/disarm the alarm or control electronic equipment connected to the module's **PGMx** output.

Call the number of the SIM card inserted into the **FLEXi SP3** security control module. If the phone number you are calling from is specified in the module's memory, the control panel will answer the call and you will have to enter the control command (see control command table).

**List of commands that can be entered via phone keypad**

Keypad buttons	Function	Description
[1][partition no][#]	Arm selected alarm system partition	E.g. (arm partition 2): <b>12#</b>
[2][ partition no][#]	Disarm selected alarm system partition	E.g. (disarm partition 2): <b>22#</b>
[3][output no][#][stay no]	Control selected output OUT	Controls a specified output OUT. State: [0] – output turned off; [1] – output turned on; [2] – turned off for pulse time; [3] – turned on for pulse time; (pulse time is specified using <b>TrikdisConfig</b> software, in the PGM table) E.g. (set output 1OUT to “on” state): <b>31#1</b> E.g. (set output 2OUT to “on” state for <b>Pulse time</b> specified in the <b>TrikdisConfig</b> “PGM” table): <b>32#3</b>

If the **Re-ARM** function is activated, if the **Delay** zone is not violated after the set entry time passes from the moment of the alarm disarm command, the alarm system will automatically return to the previous security mode.

## 9 Control using SMS messages

Using SMS messages, you can control the **FLEXi SP3** security control panel and change some of the panel's parameters. Only **TrikdisConfig** software can change all parameters of the module.

Structure of an SMS message: Command <sub>space</sub> Password <sub>space</sub> Data

For a control panel with default settings, the SMS password is **123456**. For safety reasons, we recommend changing it to a combination only you know and not forgetting it!

**SMS command list**

Command	Data	Description
INFO		Request information about the control panel. Object name, partition state, IMEI number, GSM signal strength, firmware version and serial number will be included in the reply. E. g.: <b>INFO 123456</b>
RESET		Reset the device. E.g.: <b>RESET 123456</b>
OUTPUTx	ON	Turn on an output, “x” is the output number. E.g.: <b>OUTPUT1 123456 ON</b>
	OFF	Turn off an output, “x” is the output number. E.g.: <b>OUTPUT1 123456 OFF</b>
	PULSE=ttt	Turn on an output for a specified time - “x” is the output OUT number and “ttt” is a three-digit number that specifies pulse time in seconds. E.g.: <b>OUTPUT1 123456 PULSE=002</b>
PSW	New SMS password	Change SMS password. E.g.: <b>PSW 123456 654123</b>
TIME	YYYY/MM/DD,12:00:00	Set date and time. E.g.: <b>TIME 123456 2020/01/02,12:23:00</b>



Command	Data	Description
<i>TXTA</i>	<i>Object name</i>	Specify object name. E.g.: <b>TXTA 123456 House</b>
<i>RDR</i>	<i>PhoneNR#SMStext</i>	Forwards SMS messages to the specified number. The phone number must start with a "+" symbol and the international country code. E.g.: <b>RDR 123456 +37061234567#forwarded text</b>
<i>ASKI</i>		Send SMS message with statuses of inputs IN. E.g.: <b>ASKI 123456</b>
<i>ASKO</i>		Send SMS message with statuses of outputs OUT. E.g.: <b>ASKO 123456</b>
<i>ASKA</i>		Send SMS message with statuses of partitions. E.g.: <b>ASKA 123456</b>
<i>ASKT</i>		Send SMS message with values of all temperature sensors. E.g.: <b>ASKT 123456</b>
<i>DISARM</i>	<i>SYS:x</i>	Disarm the alarm, "x" is the partition number (1-8). E.g.: <b>DISARM 123456 SYS:1</b>
<i>ARM</i>	<i>SYS:x</i>	Arm the alarm, "x" is the partition number (1-8). E.g.: <b>ARM 123456 SYS:1</b>
<i>STAY</i>	<i>SYS:x</i>	Arm partition "x" in Stay mode, "x" is the partition number (1-8). E.g.: <b>STAY 123456 SYS:1</b>
<i>SLEEP</i>	<i>SYS:x</i>	Arm partition "x" in Sleep mode, "x" is the partition number (1-8). E.g.: <b>SLEEP 123456 SYS:1</b>
<i>FRS</i>		Resets the fire sensor's output, if the output OUT is assigned the function "Fire sensor reset". E.g.: <b>FRS 123456</b>
<i>SETN</i>	<i>PhoneX=PhoneNR#Name#email</i>	Add a phone number, username and assign it to user "x". "x" is the phone number's line on the list. The phone number must start with a "+" symbol and international country code. The phone number and username must be separated by a # symbol. E.g.: <b>SETN 123456 PHONE5=+37061234567#JOHN#john@trikdis.com</b>
	<i>PhoneX=DEL</i>	Delete phone number and username from the list. E.g.: <b>SETN 123456 PHONE5=DEL</b>
<i>UUSD</i>	<i>*Usd code#</i>	Sends a UUSD code to the operator. E.g.: <b>UUSD 123456 *245#</b>
<i>CONNECT</i>	<i>Protegus=ON</i>	Connect to Protegus cloud service. E.g.: <b>CONNECT 123456 PROTEGUS=ON</b>
	<i>Protegus=OFF</i>	Disconnect from Protegus cloud service. E.g.: <b>CONNECT 123456 PROTEGUS=OFF</b>
	<i>Code=123456</i>	Protegus cloud service code. E.g.: <b>CONNECT 123456 CODE=123456</b>
	<i>IP=0.0.0.0:8000</i>	Specify the main server's connection channel's TCP IP and Port. E.g.: <b>CONNECT 123456 IP=0.0.0.0:8000</b>
	<i>IP=0</i>	For turning off the main channel. E.g.: <b>CONNECT 123456 IP=0</b>
	<i>ENC=123456</i>	TRK encryption key. E.g.: <b>CONNECT 123456 ENC=123456</b>
	<i>APN=Internet</i>	APN name. E.g.: <b>CONNECT 123456 APN=INTERNET</b>
	<i>USER=user</i>	APN user. E.g.: <b>CONNECT 123456 USER=User</b>
<i>PSW=password</i>	APN password. E.g.: <b>CONNECT 123456 PSW=Password</b>	



## 10 Control of PGM outputs

With the keypad you can control the PGM outputs. In the *TrikdisConfig* program (**PGM / Control**), it is necessary to assign the PGM outputs and the type of operation (Level or Pulse) to the utility keys. Pressing (or pressing and holding) the appropriate keys on the keypad will activate the assigned PGM output.

Utility key	Keypad utility key			Note
	TM50, TM70 (press)	Paradox (press and hold 3 sec.)	Protegus SK232W (press and hold 5 sec.)	
Utility key 1	Utility key 1	1+2	2	View the status of the control panel partitions on the Paradox LED and Protegus SK232W keyboards. Paradox LCD, TM50, TM70 keyboards ignore this utility key.
Utility key 2	Utility key 2	4+5	5	Must be assigned PGM output.
Utility key 3	Utility key 3	7+8	8	Must be assigned PGM output.
Utility key 4	Utility key 4	2+3	3	Must be assigned PGM output.
Utility key 5	Utility key 5	5+6	6	Must be assigned PGM output.
Utility key 6	Utility key 6	8+9	9	Must be assigned PGM output.



### Information about the protected object

Fill in the following tables. Keep this document in a safe location.

#### Access codes

Your Administrator code is \_\_\_\_\_

Other access codes:

No.	Code	Control key No.	No.	Code	Control key No.
01A			21		
02A			22		
03A			23		
04A			24		
05A			25		
06A			26		
07A			27		
08A			28		
09			29		
10			30		
11			31		
12			32		
13			33		
14			34		
15			35		
16			36		
17			37		
18			38		
19			39		
20			40		

#### Zones

Zone	Protected space	Zone type
01		
02		
03		
04		
05		
06		
07		
08		
09		



<i>Zone</i>	<i>Protected space</i>	<i>Zone type</i>
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		

**Temperature sensors**

<i>Sensor</i>	<i>Serial number</i>	<i>Controlled space</i>	<i>Max. temperature</i>	<i>Min. temperature</i>
01				
02				
03				
04				
05				
06				
07				
08				

