


Honeywell

RF-HW WIRELESS EQUIPMENT RECEIVER

for Honeywell equipment

The RF-HW wireless transceiver is designed to work with FLEXi SP3 and Honeywell wireless equipment. The transceiver is easy to connect to the FLEXi SP3 control panel and ensures a reliable and secure connection. The transceiver can be used with a variety of Honeywell protocol-enabled equipment, such as wireless sensors, including door, window, motion sensors, keypads, and more.



- No settings required**
- Compatible with Honeywell Home WL**
- RS485 interface**

- RS485**
- LEARN**
- POWER**

10-16V
0.25A Max

- < +DC
- < - DC
- < A RS485
- < B RS485